



**SOUTHERN
PINE PRODUCTS**

Door Jambs DIY Guide

Sizes available

Pine Fingerjoint Preprimed Flat Jamb 92 x 18
Pine Fingerjoint Preprimed Flat Jamb 115 x 18
Pine Fingerjoint Preprimed Grooved Jamb 114 x 30
Pine Fingerjoint Preprimed Grooved Jamb 136 x 30

Pine Clears Flat Jamb 92 x 18
Pine Clears Flat Jamb 115 x 18
Pine Clears Grooved Jamb 114 x 30
Pine Clears Grooved Jamb 136 x 30

Creating green building solutions



This set includes:

Door Jamb

2 lengths @ 2.1 (door style)
1 length @ 760mm (head) or 910mm (head)

Door Stop

(30x10) 2 lengths @ 2.1
1 length @ 760mm or 910mm



Required Tools:

Hammer, Hand Saw, Nails, Tape Measure,
Spirit Level, Packing material eg. shims .
malfoid



STEP 1

Measure the opening (remember to measure twice and cut only once). If less than the supplied Jamb head length is required cut your Jamb head to fit the opening. The Jamb head or style can either be butt jointed or mitred using a mitre saw.



STEP 2

Nail the Jamb head to the Jamb sides (styles) ensuring they are lined up evenly on each side, then place the complete Door Jamb into the framed opening. Packing material may be required to square up the Jamb. Double check with a level before nailing in place.



STEP 3

The jamb is now ready for door installation. After the door has been hinged the door stop will need to be fitted to the Jamb. Once the door stop is on correctly, allowing the door to open and close freely, the door stop can be nailed off.



STEP 4

You are now ready for your finishing. Firstly fill all nail holes with wood putty or something similar. If painting, a light sand between coats is required for a superior finish. Any standard finishing system whether oil based or acrylic can be applied for the final coats. Further information on painting or staining should be obtained from the paint manufacturers.

